

Forum

Classifieds

Garage Today's Posts FAQ Calendar Forum Actions Quick Links

Blogs

If this is your first visit, be sure to check out the FAQ by clicking the link above. You may have to register before you can post: click the register link above to proceed. To start viewing messages, select the forum that you want to visit from the selection below.

Insurance

Gallery

Auto Escrow

↑ Forum Volkswagen Passat Discussion Volkswagen Passat B6 Discussion

DIY - Removing front door window, subframe, door lock, handle, window regulator, etc.

What's New?

Custom Search

Advertise

Search

Auto Loans

Welcome to VW Passat Forums: Volkswagen Passat Forum â€" General discussion forum for Volkswagen Passat



Register

Welcome to VW Passat Forums: Volkswagen Passat Forum - a website dedicated to all things Volkswagen Passat.

You are currently viewing our forum as a guest, which gives you limited access to view most discussions and access our other features. By joining our community, at no cost, you will have access to post topics, communicate privately with other members (PM), respond to polls, upload content and access many other special features. Registration is free, fast and simple, Join VW Passat Forums: Volkswagen Passat Forum today!

Results 1 to 13 of 13

» Site Navigation

- » Home
- » Volkswagen Passat Insurance
- » Auto Insurance Quotes for your Volkswagen Passat Results
- » forum_landing» content_wrapper_wide
- » Active Topics
- » Bloa
- Blog Entry
- » Not_Forum_Section
- » Home
- » Active Topics
- » Photo Gallery
- » Garage
- » Forum
- > Settings
- > FAO
- > Classifieds
- > Contact Us

Thread: DIY - Removing front door window, subframe, door lock, handle, window regulator, etc.

5 Likes

#1

» Auto Insurance

» Wheel & Tire Center

04-13-2013, 08:17 PM

+ Reply to Thread

kreka o

1st Gear

Join Date: Apr 2012

Location: Fond du Lac, WI Posts:

154

DIY - Removing front door window, subframe, door lock, handle, window regulator, etc.

Here's a write up for taking the front door apart on a 2007 Passat 2.0T. I took the driver door apart, but I imagine the same steps would apply to working on the passenger door.

This write up is useful if you want to replace a window, door handle, door lock, door lock cylinder, window regulator, window regulator motor, subframe, ... pretty much anything behind your door trim.

All right, here we go.

» Forum Threads

1999 1.8t Problem with...

Yesterday 07:26 PM by Hardwurkindaddy

Last post by Freezer1328 Yesterday 11:24 PM

1 Replies 31 Views Noobs - all must

read... 02-05-2015 04:46 PM

by Urlik

Last post by symotorsport Yesterday 10:45 PM

Q

2.853 Renlies 220.013 Views

Pyou must make two 🖉 posts... 03-28-2011 07:59 AM

by JayTheSnork

Last post by symotorsport Yesterday 10:43 PM

12,851 Replies 672,198






- 1. First remove the door trim. To do that you need to
- a) pry up the handle cover I used a butterknife
- b) disconnect two electrical connectors



c) remove three T30 screws behind the door handle cover (red circles above), and two T20 screws at the bottom of the door panel trim (not shown) d) Now you need to pull the trim off the door. There are six clips holding the trim to the door – 3 on each side. I used a butterknife to find them, and then I pulled the door trim off the door.



by Reedster

Last post by Reedster Yesterday 08:15 PM

15 Replies 264 Views

Vibration after... 10-15-2017 07:13 AM

by criz0712
Last post by criz0712
Yesterday 07:59 PM

2 Replies 57 Views

Shudder in 1st and

2nd... 10-21-2017 01:39 PM by rhauff

Last post by rhauff Yesterday 07:46 PM

4 Replies 92 Views

Good All Season... 10-17-2017 06:02 AM

by BeastMode85
Last post by GrandpaBill
Yesterday 04:48 PM

1 Replies 67 Views

New RLine Passat 09-23-2017 07:26 PM by downtime

Last post by downtime Yesterday 12:31 PM

9 Replies 332 Views

Switch up to LEDs

with... 02-13-2017 05:09 AM by CARID

Last post by tippet5x Yesterday 11:48 AM

1 Replies 277 Views

Some B5.5 parts for

sale 09-12-2016 02:38 PM by exbostonian

Last post by b5n925 Yesterday 10:36 AM

1 Replies 386 Views

e) Disconnect the electrical connector circled in red above. To do it, just pry the purple clip up and it will come out.




- f) Remove the door handle cable from the door handle. Be careful not to break the cable holding tabs as they are tiny.
 g) The trim is now free and can be set aside.
- 2. Next, you need to remove the door handle and door lock cylinder.



- a) There are covercaps covering bolts circled in blue and red. Remove them. b) Remove the bolt circled in RED (Torx T15) completely out. Read next very carefully.
- c) Now go onto the bolt circled in BLUE (Torx T15). DO NOT REMOVE THIS BOLT COMPLETELY. Pull the door handle out and start loosening the bolt circled in blue. The door handle will be stuck in its pulled-out position once you turn that bolt loose a few turns, and DO NOT TRY TO PUSH IT IN.



- d) Keep slowly loosening the bolt circled in blue, while at the same time trying to pull the lock cylinder out. You can turn the bolt loose one turn, and then try to pull the cylinder out. Keep doing it until you can pull the cylinder out. Now I'll say it again: DO NOT REMOVE THE BOLT CIRCLED IN BLUE COMPLETELY. Loosen it just enough so you can get the cylinder out.
- e) Once the cylinder's out, you can remove the door handle. To do so, you need to
- Pull the door handle towards the rear of your car a little bit
- Then swivel it outside out of its bracket
- Remove it from the door
- 3. Once the door handle and lock cylinder are out you can begin removing the subframe.



- a) Pull the cover caps circled in blue off.
- b) Now you need to lower the window. To lower it you have to reconnect the electrical connector from your door trim back to the window regulator. Lower the window until you can see the screws (you need E5 socket they are "socket torx" screw for the lack of a better term) holding the window brackets tight. THESE SCREWS HAVE LEFT HAND THREADS. If you don't know what it means (not trying to offend anybody), to loosen them you need to turn them clockwise, and to tighten them you need to turn them counterclockwise. Exactly the opposite of how things should be.
- c) Once the screws are loose you can remove the window. If you are replacing the window, you can pull it out of the door frame now. If your goal is something else, have some duct tape handy. Pull the window up and tape if to the door window frame so it doesn't fall down.
- d) On window regulator, disconnect the side mirror electrical connector (circled in red) and guide the cable free and away from the subframe (red lines).
- e) Disconnect the electrical connector circled in orange, and pull the clip holding the cable to the door out (orange circle).





- f) Now you need to disconnect the main electrical harness from the door to the car. If you look at the place where your door meets the car you'll see a rubber "snorkel" or protective boot. At the car side, the boot has two tabs. The bottom one is fixed. The upper one can be pushed up. So push the upper tab up and pull off the boot on the car side.
- g) Once the boot's off, pull the harness connector lock (clip) down and disconnect the harness from the car.
 h) Push the boot and main harness connector (circled in red) into the door.



i) Remove the door lock bolts (2 M6 bolts)



j) Remove screw circled in yellow (T20), and then pull of the door handle bracket "gasket" (red arrow). Pay attention to how it's installed. k) At this point you can remove all the bolts securing the subframe (subframe picture – yellow circles)



I) Make sure the door handle bracket is free from the door when you remove that "gasket" (red circle), and then pull the subframe up a little bit, tilt the bottom out, and pull it downwards out from the door frame.

Forgot to add that installation is reverse of removal. A couple points though:


1. When you guide the main harness through the door back out, make sure the door end is reseated right in the door frame. Then you bolt the subframe on. This way you don't find the harness being pulled into the door frame all of a sudden - which incidentally happened to me


- 2. Note about the main harness it is held by a clip to the subframe so that it stays out of the window downpath. If you accidentally break that clip so the harness has a lot of play and is loose, make sure you tie it in some way to the subframe so it doesn't swing out in the window down path
- 3. When you're ready to put the window down, slide the window brackets down a little bit so that you can actually see and make sure the window sits in the window brackets. Then push on the window down a little bit to seat it fully in the brackets. Then, raise the window electronically so you can access the bracket screws. This way you'll make sure the window is fully seated in the brackets.
- 4. With the main harness disconnected do not turn the car on, as an airbag warning will pop up airbag side crash sensor is diconnected. If you have a means of resetting it it's fine.

Any suggestions, comments, etc. are welcome. Note, will take donations in BEER ONLY

Last edited by kreka; 04-14-2013 at 06:21 PM. Share RichardSEL, Tooch, jbl1 and 2 others like this. Reply **Reply With Quote** Remove Advertisements **VW Passat Forum** Advertisements #2 04-13-2013, 09:00 PM Great post! Hope you've got the pictures hosted somewhere where they'll be jddaigle o available for the long haul. If I was closer to MI you'd get a beer for sure. 1st Gear Join Date: Nov 2004 Location: Colorado Posts: 225 Share --leff 2008 B6 Passat Wagon 3.6 4motion Reply **Reply With Quote** 04-14-2013, 03:14 AM #3 RichardSEL o Great write up. And good pix too 2nd Gear For us this side of the pond what year and variant of B6? Join Date: Jan 2009 Location: LONDON, U.K. 890 Posts: Share Reply With Quote Reply Remove Advertisements Sponsored Links **VW Passat Forum** Advertisements #4 04-14-2013, 06:20 PM It is a 2007 2.0T FSI Sedan. I suppose the process would be the same for all kreka o B6 models, unless higher ups don't have additional controls on the door 1st Gear handle. Thanks for the question, I'll update the post. Join Date: Apr 2012 Location: Fond du Lac, WI Posts: 154 Share Reply **Reply With Quote** 04-15-2013, 05:23 PM I have had success using plastic kitchen tools, say a spatula or flipper, in place turtle o of the butterknife for prying off parts. The wider softer edge is a bit more 3rd Gear forgiving on the trim. Join Date: Jan 2004 Location: Vacationland 2,410 Posts: Share Reply **Reply With Quote** 07-10-2013, 06:16 PM Do you know of any way to "shorten" the cable for the handle to open up the donasmello o door from the inside? My cable seems to be overextended because when it is Neutral hooked to the handle it has no tension and the door won't open from inside handle. Join Date: Apr 2012 Location: Georgia







All times are GMT -7. The time now is 12:10 AM. vBulletin Security provided by vBSecurity v2.2.2 (Pro) - vBulletin Mods & Addons Copyright © 2017 DragonByte Technologies Ltd.

Digital Point modules: Sphinx-based search

Terms of Use

AutoGuide.com		Manufacturer	Domestic	Import	European	Truck	AutoGuide.com
AcuraWorld.com	FordInsideNews.com	MazdaWorld.org		ScionForum.com			
Audi-Forums.com	GMinsidenews.com	Mini2.com		SaabScene.com			
BenzForum.com	Hyundai-Forums.com	Mitsubishi-Forums.com		5	SRTforums.com	1	
BenzWorld.org	HyundaiPerformance.com	Volvo-Forums.com		9	SuperHonda.co	<u>m</u>	
BimmerWerkz.com	Kia-Forums.com	Nissan-Sites.com		5	Suzuki-Forums.	com	
DodgeTalk.com	Lamborghini-Talk.com	NissanClub.com		I	ToyotaNation.co	<u>m</u>	
Ferrari-Talk.com	LandRoversOnly.com	NissanForums.com		VWforum.com Noreast			
FordForums.com	LotusTalk.com						