

HI-FLO TURBO DISCHARGE CONVERSION - PART #48.02.71

2008.5-UP AUDI A3 2.0 TSI, 2008.5-UP AUDI TT 2.0 TSI, 2008.5-UP VW CC, EOS, GTI, JETTA V, PASSAT & TIGUAN 2.0 TSI FITS ENGINE CODE CBFA & CCTA

PARTS LIST:

- 1 BILLET TURBO DISCHARGE ADAPTER
- 1 ALUMINUM PIPE
- 1. Raise the vehicle and support with jack stand(s) under lifting points. **Never** work on a vehicle supported only





Undo the (8) T25 Torx screws to remove lower engine pan. Now remove the passenger side lower inner fender liner there are (5) T25 Torx in the fender well and (2) T25 Torx on the bottom of the front bumper cap. **NOTE:** Some models may vary slightly.

- 1 2 ¼" SILICONE HOSE
- 2 #36 HOSE CLAMPS

TOOLS REQUIRED:

- 1 T25 TORX
- 1 SCREWDRIVER
- 1 T30 TORX 1 - RATCHET
- 1 8mm SOCKET OR NUTDRIVER
- 2 JACK STAND


1 - VEHICLE JACK

with a jack!





3. Use screwdriver to pull-out clip to release rubber intercooler hose from plastic pipe.



4. Unbolt plastic pipe from engine just below crankshaft pulley, (2) T30 Torx.





5. Pull-out clip to release rubber hose from turbo discharge.





Carefully remove O-ring seal from original discharge hose and install onto NEUSPEED adapter.



7. Lightly oil O-ring and install adapter into turbo making sure it locks into place.



8. Install and tighten silicone hose to adapter using supplied #36 clamp.



9. Pull-out mounting screws then rubber grommets from original pipe and install onto NEUSPEED pipe.



10. Loosely install second #36 hose clamp onto silicone hose. Now connect NEUSPEED discharge pipe to silicone hose and attach mounting points to engine. First tighten mounting screws then tighten second hose clamp.



11. Again, lightly oil O-ring on intercooler hose and then install into NEUSPEED discharge pipe making sure it locks into place.



12. Double check complete installation and reinstall fender well liner and lower engine pan.

©Copyright 2009, NEUSPEED® All rights reserved. Reproduction in whole or in part prohibited. DOC.48.02.71 Rev. 07.14.09