
GOLFMK7 GOLFMK6 GOLFMKV FORUM OPTIONS PRIVATE MESSAGES Welcome, LateAPXR. /// Log Out Private Messages: Unread 0, Total 45 User CP Timeslips Members List New Posts MYGOLF garage Search V Community V Ouick Links Quick Links 🛡 YOUR FORCED VW GTI Forum / VW Rabbit Forum / VW R32 Forum / VW Golf Forum - Golfmkv.com > Technical Discussions > DIY + Maintenance + Tips/Tricks Meat's Brake DIY (w/ thanks to DanGSR) SPECIALISTS POST REPLY Page 1 of 20 1 2 3 4 5 11 > Last » 🗸 View First Unread Thread Tools 🔽 Search this Thread 🗸 Rating: 🛧 D2-10-2008, 07:37 PM Meat's Brake DIY (w/ thanks to DanGSR) <u>Meat</u> rack rack 'e DISCLAIMER: Neither I nor any other members who have lent their advice or expertise to the writing of this DIY take any responsibility for any (personal property or injury to yourself... Tools needed: - 2 ton Jack and jack stands (preferably 4) - 17mm deep socket or 17mm socket with extension (for lug nuts) - torque wrench (optional-to tighten lugs to spec) - 13 mm socket (or wrench) - 21 mm socket Drives: '07 GTI - 15 mm wrench (SOLD) Join Date: Oct - M14 triple square bit. I recommend these: http://www.amazon.com/Pc-XZN-Bit-Dri...9184466&sr=8-2 - T30 bit or driver 2006 Location: Cincinnati, OH - Socket wrench with a breaker-bar - Piston reset tool, available to rent from AutoZone or buy it here: http://www.metalnerd.com/cat08.htm Posts: 7,884 - Anti-squeal paste 2 - Brake and caliper grease - 7 mm allen key - piers **Rear Brake Pads and Rotors** ****If you are only going to swap pads, skip steps 4-6**** 1. Loosen all lug nuts. Jack up car and remove wheels, always use jack stands, NEVER work on a car supported by only a jack



2. Remove the two bolts from back of the caliper using 13 mm and 15 mm wrenches



3. Remove the caliper, rest it on a jack or zip-tie it up so that the lines don't stretch



4. Remove the two bolts holding on the carrier using an M14 twelve point bit.



5. Remove the carrier and remove the old pads from it. Set it aside.



6. Using a T30 bit, remove the screw holding on the rotor and remove the rotor



7. Sparingly apply some anti-squeal paste to the back of the pads, be sure to not let ANY of it touch the surface of the rotors or pads. Spread it w plastic shopping bag or other clean-disposable spreader



8. Place the pads in the slots in the carrier



9. Replace the rotor and bolt the carrier back on, place some grease on the carrier bolts

10. Using the piston resetting tool, compress the piston as far as possible



11. Slide the caliper onto the carrier and bolt the caliper back on



12. Check all of the bolts to make sure that they are tight. Make sure that your lines are not leaking at the fittings, and make sure that the rotors clean. You can spray them with Brake Cleaner to make sure, but do not let the brake cleaner touch the brake pads

13. Repeat for the other side.

Front Brake Pads and Rotors

****If you are only going to swap pads, skip steps 4-6****


1. Remove the metal clip holding the front caliper to the carrier using a large flathead screwdriver or pliers



2. Remove the black plastic caps covering the bolt that hold the caliper on. Using a 7 mm allen wrench, remove both of the bolts.



3. Remove and secure the caliper so that the lines aren't stretched



4. Using a 21 mm socket, remove the bolts that hold on the carrier



5. Then remove the carrier and the screw that holds the rotor on, remove the old pad from the carrier



6. Replace the rotor and the screw that holds it on, then lightly grease the carrier bolts and bolt the carrier back on

7. Pull the old inboard pad off of the caliper

8. Sparingly apply some anti-squeal paste to the back of the outboard pad, be sure to not let ANY of it touch the surface of the rotors or pads, pla pad in the carrier

9. Using a pair of pliers, squeeze the metal tabs on the back of the inboard pad to get them to fit inside the caliper hole, be sure to not contamina surface of the pad

10. Using either your hands, piston resetting tool, or a C-clamp, compress the piston all of the way

11. Slide the caliper onto the carrier and over the pad already on the caliper

12. Lightly grease the bolts that you removed from the caliper and bolt the caliper back on using the 7 mm hex key and replace the black caps an

on the outside of the caliper using a pair of pliers. 13. Repeat for the other side. NOTE: if your pads come with wear-sensors, you will have to unplug the cable from the old pad and plug it into the the new pad. The pad with the wear sensor is the inboard pad on the front left side.



Finishing up

- 1. Place the wheels back on and tighten the lugs hand tight
- 2. Lower the car and torque the lugs to 88.5 ft/lbs 120 Nm)

3. Start the car and pump the brakes until they are firm. Your brakes may feel funny for the first 200 feet so make sure you aren't in danger of hi anything or rolling into anything.

4. Follow the bedding procedure outlined in the paperwork that came with your brakes. This usually involves making a few hard stops from variou

Changine Brake Lines

You can change your brake lines before changing the pads/rotors or afterwards, it doesn't really matter. Just be sure to properly bleed the brakes are finished.

Here is a good write-up on line changing from Neuspeed. Thanks to xSabertoothX for the link: <u>http://www.neuspeed.com/installation/brakes.asp</u> (Download PDF)

Torque Specs


Guide pins on the front caliper: 30 Nm Front carrier bolts (21mm): 190 Nm Hex bolts on the rear brake caliper: 35 Nm 12-point bolts that hold rear carrier: 90 Nm + 90 degrees


Rotor set screws: 4 Nm Brake lines: 14 Nm

Anile-Eights DIY for adjusting the Parking Brake: http://golfmkv.com/forums/showthread.php?t=143861

Brake Bleeding Links:


Google "brake bleeding mkv gti" and click the first result to find a DIY. Here is more info on the order specified in the Bentley Manual http://www.golfmkv.com/forums/showthread.php?t=91184







Meat's Brake DIY (w/ thanks to DanGSR) - VW GTI Forum / VW Rabbit Forum / VW R32 Forum / VW Golf Forum - Golfmkv.com

5/12/13 2:02 PM









http://www.golfmk5.com/forums/showthread.php?t=40013&highlight=lug+torque

Meat's Brake DIY (w/ thanks to DanGSR) - VW GTI Forum / VW Rabbit Forum / VW R32 Forum / VW Golf Forum - Golfmkv.com





All times are GMT -4. The time now is 02:01 PM.

Contact Us - VW GTI Forum / VW Rabbit Forum / VW R32 Forum / VW Golf Forum - Golfmkv.com - Archive - Top

Powered by vBulletin® Version 3.8.0 Copyright ©2000 - 2013, Jelsoft Enterprises Ltd.